

MESSMER'S

NATURAL WOOD FINISHES



U.V. PLUS

NATURAL WOOD FINISH

DESCRIPTION: U.V. Plus is an oil based penetrating wood finish suitable for decks, log homes, wood siding, fencing and other exterior wood surfaces. U.V. Plus protects wood while maintaining a natural appearance.

SPECIFICATIONS

VEHICLE TYPE

Solvent borne blend of natural oils and alkyds

COLORS

Available in Natural, Natural Pine / Fir, Natural Cedar, Natural Redwood, Sequoia Red, Navajo Red, Oxford Brown, Dark Walnut, Oak Brown, Colorado Brown, Lakeside Brown, Mission Oak, Driftwood Gray, Cape Cod Gray and Charcoal Gray

VISCOSITY

15-18 seconds Zahn #2 at 77F

VOC CONTENT

MC / MS Series	<450 g/L (as supplied)
CMC / CMS Series	<250 g/L (as supplied)
LMC and LMS Series	<100 g/L (as supplied)

SOLIDS BY VOLUME

MC / MS Series	Approx 45%
CMC / CMS / LMC / LMS Series	Approx 55-60%

SOLIDS BY WEIGHT

MC / MS Series	Approx 50%
CMC / CMS, LMC / LMS Series	Approx 60%

WEIGHT PER GALLON

7.3 to 8.5 lbs

COVERAGE

Rough Wood:	100 to 150 square feet per gallon
Smooth Wood:	150 to 250 square feet per gallon

DRY TIME

Allow 24 hours in good drying conditions

APPLY WITH

Brush, applicator pad, roller, garden sprayer, airless sprayer

PACKAGING

One gallon and five gallon containers

SURFACE PREPARATION

Always clean gray or dirty wood before applying UV Plus. Use Messmer's WD Wood & Deck Cleaner (A) and Brightener (B) available in powder concentrates. Allow wood to completely dry for at least 24 to 48 hours. Previously stained or treated wood should be sufficiently weathered to allow for complete penetration. New redwood should be aged at least 6-8 weeks and cleaned and brightened before applying product.

SPECIAL INSTRUCTIONS

Before applying, this product should be mixed thoroughly. Ensure that all settled material on bottom of can is evenly incorporated, and intermix all containers (box them).

Apply UV Plus when surface temperatures are between 45F and 90F. If surface is hot to the touch, it is too hot to apply product. Do not apply product if precipitation is expected within 24-48 hours.

Spray Application: When spraying, back brush or roll to prevent sags and runs. Cover surrounding areas to protect from overspray. For airless spray, use .015" to .019" tip size for best results.

Brush Application: To minimize lapping, maintain a wet edge lengthwise and do not break in the middle of boards.

One coat is sufficient for most applications. Product not absorbed into the wood within 30-60 minutes must be removed to prevent surface sheen.

THINNING RECOMMENDATIONS

Thinning is not recommended.

CLEANUP

Use paint thinner. Dispose of waste in accordance with local, state and federal regulations.

Danger - Rags, steel wool or waste soaked with UV Plus may spontaneously catch fire if improperly discarded. Immediately after each use, place rags, steel wool or waste in a sealed, water filled metal container.